

transformer.

WORK INSTRUCTION

Page: 1 of 1 Work procedure: Fitting LV boards to KL base. This document is 1. With the enclosure removed 2. If DM&C equipment is installed remove 3. Remove 2 X M10 fixing bolts from uncontrolled and intended to disconect the flexible connections wiring and fittings from the L/V Board. R.H.S of galvanised chanel base. be used as a guide to from the transformer bushings. replacing equipment in the field. Schneider Electric have not commented or issued any reference to OH&S or quality procedures which are the responsibility of Ausgrid. 5. Disconect 2 X earth leads from earth 4. Remove 2 X 6. Use 2 X lifting points to remove M10 fixing bolts the disconected board. Ensure the bar. from L.H.S board is lifted gently so as not to damage the transformer bushings. 7. Reverse the procedure to install a board. Procedure 3 should be used when re-connecting the board to the